

# GARAGE DOOR JAMB WRAPS

1. Pull trim away from the bottom of the jamb.
2. Determine jamb size and snap off wrap end to fit.
3. Slide jamb wrap behind trim and set on concrete.
4. Using screws/nails, secure front of jamb wrap.
5. Using screws/nails, secure side of jamb wrap.
6. Reinstall trim back on jamb.
7. Apply a small bead of clear silicone along top edge of jamb wrap to seal and protect jamb.

