

Place Verifi Vertically In a Location Where It Cannot Be Moved

Caution: Verifi should not be placed near open flames or heat sources

Verfi Wall Bond Options

Option A: Verifi Adhesive Backing

For hard surfaces, remove the plastic backing covering the adhesive on the Verifi Holster and affix the Verifi Holster to the hard surface mounting target, ideally mounted in contact with or closely adjacent to the area where bed bugs are expected to be. Bed bugs are most commonly found in beds and other frequently used furniture (ex: mattress and headboard).

Caution: The adhesive may cause damage to paint and drywall when the detector is removed



Option B: Utilize the Verifi Back Plate for Mobility

1. Locate the four mounting holes on the back plate and the orientation **arrow indicating UP**.
2. Hold the back plate in the mounting location and mark the wall with the four holes using a pencil. NOTE: All four holes are necessary.
3. Using a drill suited to the wall anchor size bore the holes in the wall board
4. Insert the wall anchors and mount the back plate with the Phillips flathead screws
5. Snap the Verifi Bed Bug Detector top in first!

