

Technical Information

Subject: Correct Starting Procedure for Solo Models 451 and 467

Models: 451 and 467

The Solo Model 467 backpack blower and the Solo Model 451 Mistblower are both equipped with high compression engines. This high compression requires that the starter assembly be engaged before attempting to start the unit to avoid damaging the starter assembly. Engaging the starter is accomplished by gradually pulling on the starter rope until you feel it catch or engage (about 3 inches). Once you have reached this point, pull with a slow and steady force on the starter rope to start the unit.

