



BioStim, LLC
PO Box 1737
Boerne, TX 78006
Phone (800) 338-8812
Fax (830) 336-4827
www.biostim.com



BIOPLUG® CS & BIOPLUG® L

For use in lift stations and municipal sewer lines. *BioPlug* is a timed-release product. For use with *BioFloater* in lift stations.

Application Instructions:

Lift Station – Attach *BioPlug(s)* to *BioFloater*. Lower *BioFloater* into well, placing close to water inflow. Allow weight to sink approx. one foot above the bottom of the well. Tie off rope leaving no slack in line.

Sewer Line – Attach *BioPlug(s)* to rope. Lower *BioPlug(s)* into the clean out until it is dragging in the water. Tie off rope to the stairwell so that the *BioPlug(s)* remain at the bottom of the sewer line & will not wash into the enclosed pipe when water is flowing hard.

Two Week Follow-up Visit – Return in two weeks to verify how much of the *BioPlug* has dissolved. Change type of *BioPlug* if necessary.

Replace *BioPlug(s)* monthly.

Storage:

Store at ambient temperature; do not allow to freeze.

Product Information:

Environmentally friendly
Safe for plumbing lines and lift stations
Contains no corrosive or caustic chemicals
No free enzymes or FOG emulsifiers

Non-flammable
Does not cause pass-through
Multiple strains of naturally occurring bacteria

Precautions:

Do not ingest
Keep out of reach of children
Avoid contact with open wounds
People with autoimmune deficiencies should avoid contact

Do not inhale
Wear latex gloves for hygiene
Avoid contact with eyes, nose, or mouth
Wash hands with soap and water after handling

First Aid:

In case of contact with eyes: flush with water for 15 minutes; seek medical attention if irritation persists.

In case of contact with skin: wash with soap and water; remove contaminated clothing.

In case of inhalation: remove victim to fresh air if trouble breathing; seek medical attention immediately.

In case of ingestion: drink water to dilute; do NOT induce vomiting; seek medical attention immediately.

MSDS available at www.biostim.com under “Products” tab.

Rev. Jan 2012

